Quick Start Guide

MPK7836

www.curtisint.com

1. Overview

2.Music Play

1) Choose “Music” option on the main menu, click the icon to enter Playing Song Mode.

2) Click “ / ”icon to play the previous or next song.

3) Click “”icon to return to the “Audio Files List” and select your desired

4) Click “” icon to delete the chosen song.

5) Click “” icon return to the main menu when the player is playing music.

6) Click “” icon to select the “Repeat set mode” or the “EQ set mode”.

7) Push the “ON/OFF” button to set the “A-B” repeat function.

8) Click “” to “” icon to pause or play the song.

3.Video Play

1) Choose “Video” option on the main menu, click the icon to enter “Video Files List” and select your desired movie.

2) Click “” icon to delete the chosen movie.

3) Click “ / ” icon to play the previous or next movie.

4) Click “” icon return to main menu when the player is playing movie

5) Click and hold “ / ” icon to fast forwards or fast backwards.

6) Click “” or “” icon to pause or play the movie.

4. FM

1) Choose “FM” option on the main menu, click the icon to enter Playing Radio Mode.

2) Press “” to select an item in (Manual), (Preset), (mem) , (Del) and(Auto)

a) Manual: press the “ / ”, you can search the station manually.

b) Preset : Press the “ / ” to select Saved function,

c) mem: Save FM Channels

d) Del: Delete FM Channels

e) Auto: The player will automatically scan for FM channels

4) Press “” to enter recording

5. Photo view

1) Choose “Photo” option on the main menu, click the icon to enter “Photo Files List” and select your desired picture.

2) Click “” icon to delete the chosen picture.

3) Click “ / ” icon to play the previous or next picture.

4) Click “” icon return to the main menu when the player is playing picture.

5) Click “” icon, the operation icon will disappear, touch the screen the operation icon will appear.

6) Click “” to setup the browsing of picture.

7) Touch the “”, will browse automatically, while it will not work when the icon change to the “”icon.

6.Record

1) Choose “Record” option on the main menu, click the icon to enter recording mode.

2) Click “” icon to start the recording.

3) Click “” icon to pause the recording

4) Click “” icon to save the recording file.

5) Click “” icon to return the main menu.

6) Enter the “Audio File List” of the “Music” menu to choose and enter the “Voice” folder, then select and play your desired voice.

7. Text

1) Choose “Text” option on the main menu, click the icon to enter “book Files List” and select your desired article.

2) Click “” icon to delete the chosen article.

3) Click “” icon return to the main menu when the player is playing article.

4) Click “ / ” Up or Down to browse the chosen article on the full screen.

5) Click “” to save a bookmarker.

6) Click “” to load a bookmarker.

8. Navigation

1) Choose “Navigation” option on the main menu, click the icon the “Explorer Files List” and select your playing files.

2) Click “” icon to delete the chosen files.

3) Click “” icon return to the main menu.

9. Game

1) Choose “Game”option on the menu,click the icon to enter “Game”interface.Choose a game to play.

2) Button Functions: “＋” move left, “－” move right, “M” enter / shoot, “ON / OFF / HOLD” exit game menu.

3) To exit the game mode, do as follows:

-Under the browsing mode, long press “M” to return to main Menu.

-When playing the game,Push “ON/OFF/HOLD” button to pause the game. Select “QUIT” using the “+”/”-“ button and push “ON/OFF/HOLD” again to quit the game. In the ensuing screen, long press “M” to return to browsing mode. Repeat the operation to return to main menu.

4) The player can only support the game named "Pirates of the Caribbean" in .RKP format created by Rockchip. The game files must go into a folder called “Game” on your player.

10. Setting

1) Choose “Setting” option on the main menu, click the icon the corresponding setting interface.

2) Music Play: Repeat mode, EQ Setup and User EQ set,play Mode.

3) Radio Setup: Stereo Switch, FM Region.

4) Record Setup: REC Quality, REC volume.

5) Display Setup: Backlight time, Lum, Backlight mode.

6) Auto play set: There are text and jpeg under this menu: 1s,2s,3s,4s,5s.

7) System Setup: Language Selection, About, Touching screen calibrate.

8) Power Off Time: Off, 10 min., 15 min., 30min., 60min. and 120min

9) Defaulted Set.

10) Firmware Upgrading.

NOTICE:

MUTE DOES NOT WORK UNDER EARPHONE PALY MODE.

Before using this product,initial touch screen adjustment is required.

• Press “Settings” option on the main menu, enter into submenu.

• Press “System” option on the submenu and choose “Touch Calibraton”, touch the cross center for three times.